

COPY THIS PAGE OR VIEW FROM A SECOND SCREEN

The software always displays 3 tutoring models:

- (1) Accessibility to more than 60 educational videos.
- (2) Each time the cursor moves, new instructions appear on the screen.
- (3) The file below shows instructions to follow.

Summary,

| | |
|--|----|
| 1-Use one of the options displayed on the home page..... | 2 |
| 2-Adding a new project or installing an existing project. | 3 |
| 3-Selection of the steps forming the project..... | 4 |
| 4-Construction of the building foundations. | 5 |
| 5-Construction of the basement floor. | 6 |
| 6-Construction of upper floors. | 7 |
| 7-Construction of a garage | 8 |
| 8.A-Installation of parts. (Living room, Bedroom, Kitchen or others) | 9 |
| 8.B- Distribution of products in each room. (Ex: gypsum, paint, door, moldings etc...) | 10 |
| 9.A Production of identical roof panels. | 11 |
| 9.B Distribution of products to roof panels (cornice, shingles, etc.). | 12 |
| 10- Construction of concrete balconies. (Possibility of 2) | 13 |
| 11- Construction of basement terrace. (Possibility of 2) | 14 |
| 12-Project administration. | 15 |

**1-Use one of the options displayed on the home page.
Follow the instructions coming from the cursor.**

THIS PAGE SHOWS INSTRUCTIONS TO FOLLOW TO USE THE OPTIONS.

Click on the “Projects” scroll bar to select a project from the file list.

- *ADD:*

Click on the “ADD” tab to add a new project. Fill in the project identification form by validating it to display it in the “Projects” tab.

- *ACCESS:*

Click on the “ACCESS” tab to display the desired project.

- *COPY:*

Click on the “COPY” tab to repeat this project on the same site and rename it. A “REMOVE” bookmark eliminates the project appearing on the project tab.

- *DATASHEET:*

Clicking on the “DATASHEET” tab gives access to the choices of the price list available for each project.

Datasheet

- *COMMAND ORDERS:*

Clicking on the “COMMAND ORDER” tab gives access to the management of purchase orders and suppliers.

- *RESULTS:*

Click on the “RESULTS” to access the following reports (Steps Detailed - Detailed Products – *Products Compiled - Banks*) of the project.

- *KNOWLEDGE BASE :(VIDEO)*

Click on the icon at the top of the page representing a white question mark in a black circle to access the various videos (66) teaching how to install a multitude of product.

- *EDIT THE PROJECT:*

Click on the icon representing a mechanical key and complete this form to edit the project.

2-Adding a new project or installing an existing project.

Follow the instructions coming from the cursor.

THIS PAGE ALLOWS YOU TO INSTALL AN EXISTING PROJECT OR INSTALL A NEW ONE

From the home page on the screen, click **ADD** to get a new project.

A table appears or you need to name the project.

A green board appears on the screen confirming that you have saved the project. This green board should always appear after completing each box in the software.

Name

Type

Datasheet

CLICK ON SAVE

A green board appears on the screen confirming that you have saved the project. This green board should always appear after completing each box in the software.

The new project you have saved will be displayed in the list of projects. Click the project drop-down arrow and target the project in the list of projects. Click on the project you want to use and then click on the **ACCESS** cell to display it on the screen.

To access an existing project from the list, click on the drop-down arrow of projects and choose the project you want. Click on this project and then click **ACCESS** to display it on the screen.

3-Selection of the steps forming the project

Follow the instructions coming from the cursor.

CHECK BELOW THE STEPS THAT WILL FORM THE PROJECT.

- Adjustments
- Foundation
- Basement
- Basement Wall
- Concrete Balcony
- Garage
- Basement Patio
- 1st Floor
- 2nd Floor
- 3rd Floor
- 4th Floor
- 5th Floor
- 6th Floor
- Roof
- Inner Room

CLICK ON SAVE

THE ADJUSTMENTS STEP SHOULD ALWAYS BE CHECKED

**The software shows the steps you've selected at the top of the screen and hides the ones you don't use.
You can now start your project.**

4-Construction of the building foundations.

Follow the instructions coming from the cursor.

INCLUDING 2 FOUNDATION MEASUREMENTS BY DEFAULT TRANSFERRED THE RESULTS TO THE UPPER FLOORS OF THE PROJECT WHICH USE THESE MEASUREMENTS. (ADJUSTMENTS NECESSARY).

STARTING MEASURES

FLOOR FACADE

| | |
|-------|------|
| 0,000 | Foot |
|-------|------|

FLOOR SIDE

| | |
|-------|------|
| 0,000 | Foot |
|-------|------|

SAVE

Use the files below to modify the foundations, to add windows to the foundation, change the thickness of the foundation and the insulation of the walls, add interior footings etc....

BASIC FOUNDATION

_CONCRETE

_MODIFICATION

ETC..

5-Construction of the basement floor.

IF NECESSARY, OPEN THE SECTIONS BELOW TO COMPLETE THE FLOOR.

Follow the instructions coming from the cursor.

.. Use the files below as needed to add partitions, load walls, concrete blocks, etc.

THE MEASURES FROM THE " FOUNDATION " STEP ARE ALREADY INCLUDED BY DEFAULT ON THE BASEMENT FLOOR AND CEILING.

Ceiling

Wood Partition

Bearing Wall

Wall Height

Concrete Blocks

Mechanical

ALL THE BASIC PRODUCTS OF THE SUBSOIL COME DIRECTLY FROM THE RESULT OF THE FOUNDATION MEASUREMENTS

6-Construction of upper floors.

Follow the instructions coming from the cursor.

If the floor measurements have changed, use the following boxes to change them.

Choice of Dimensions



(1st) Already Programmed Dimension



(2nd) New Dimensions

ADD.

Use the files below as needed to add partitions, load walls, concrete blocks, windows, etc.

[Base Floor](#)

[Exterior Wall](#)

[Floor](#)

[Ceiling](#)

[Partition](#)

[Bearing Wall](#)

[Concrete's Block](#)

[Concrete Wall](#)

[Common Wall](#)

[Coating NO.1](#)

[Coating NO.2](#)

[Coating NO.3](#)

[Iron Angle & Accessories](#)

[Sills](#)

[Mechanical](#)

[Louver](#)

ALL THE CORE PRODUCTS OF THE UPPER FLOORS OF THE PROJECT COME DIRECTLY FROM THE RESULT OF THE FOUNDATION MEASUREMENTS.

By default, floors display the products of the floors, ceilings, and walls on each floor.

7-Construction of a garage

Follow the instructions coming from the cursor.

Enter the length and width of the garage and the software will activate the queries.

Dimension

Garage Length

| | |
|-------|------|
| 0.000 | Foot |
|-------|------|

Garage Width

| | |
|-------|------|
| 0.000 | Foot |
|-------|------|

Square Surface (to repeat)

SAVE

Use the files below to add partitions, load walls, concrete blocks, etc.

[_Solage](#)

[_Interior Solage](#)

[_Bearing Wall](#)

[_Wall Concrete Blocks](#)

[_Coating NO.1](#)

[_Exterior Solage](#)

[_Floor](#)

[_Ceiling](#)

[_Exterior Wall](#)

ALL BASIC PRODUCTS FOR THE BASEMENT, FLOOR, CEILING AND EXTERIOR WALLS OF THE GARAGE ARE DISPLAYED BY DEFAULT FROM THE INSTALLATION RESULT OF THE TWO GARAGE MEASUREMENTS.

8.A-Installation of parts. (Living room, Bedroom, Kitchen or others)

Follow the instructions coming from the cursor.

| | |
|-------|------|
| 0.000 | Foot |
|-------|------|

Length

| | |
|-------|------|
| 0.000 | Foot |
|-------|------|

[Adjust Surface \(to repeat\)](#)
[Triangular Surface \(to repeat\)](#)

Identify the project.

Confirmation

Type of Building

| | |
|------|------|
| TEXT | Unit |
|------|------|

Identification of Room.

Room Name

| | |
|------|------|
| TEXT | Unit |
|------|------|

SAVE

Stage Selection

- (1st) No Floor
- (2nd Choice) Basement
- (3rd Choice) 1st Floor
- (4th Choice) 2nd Floor
- (5th Choice) 3rd Floor
- (6th Choice) 4th Floor
- (7th Choice) 5th Floor
- (8th Choice) 6th Floor
- (9th Choice) Garage

8.B- Distribution of products in each room. (Ex: gypsum, paint, door, moldings etc...)

Follow the instructions coming from the cursor.

To complete the products and dress up the pieces, use the sections below while following the instructions in the comments.

[Products](#)

[Mechanical](#)

[Wardrobe](#)

[2nd Wardrobe](#)

[Wall Openings](#)

[Plastering](#)

[Inside Doors](#)

[Doors & Windows](#)

[Interior Stair](#)

[Kitchen](#)

[Bathroom](#)

[Floor Balcony](#)

[Wood Partition](#)

[Metal Partition](#)

[Ventilation](#)

9.A Production of identical roof panels.

Follow the instructions coming from the cursor.

Identify the number and type of identical panels used.

Identical Panels

Quantity

Unit



(1s) None



(2nd) Four Square Angles



(3rd) Two Square Angles



(4th) One Square Angle or Less

SAVE

Enter the dimensions of the panels.

Panel Measurements

Top of Panels

Foot

Bottom of Panels

Foot

Height

Foot

Slope

Unit

SAVE

9.B Distribution of products to roof panels (cornice, shingles, etc.).

Follow the instructions coming from the cursor.

Choosing the thickness of the cornices

Cornice Columbine

2 " X 4 " x 12 '

Unit

2 " X 6 " x 12 '

Unit

2 " X 8 " x 12 '

Unit

2 " X 10 " x 12 '

SOFFITE

LOCALISATION SOFFITE

BAS DES PANNEAUX

Inch

CORNICHES DE PIGNON

Inch

Use the files below to add different products to the roof, etc.

[_Roof Products](#)

[_Roof Pinion](#)

[_Carport](#)

[_Common Roof](#)

[_Chimney](#)

[_Ventilation](#)

[_Flat Roof with Trust](#)

[_Balcony](#)

10- Construction of concrete balconies. (Possibility of 2)

Follow the instructions coming from the cursor.

Enter the length and width of the balcony and the software will calculate and compile all the products of the slab, slab reinforcement etc.

Square Surface (to repeat)

ACCESSADDREMOVE

Length

Width

[Square Surface Adjustment \(to repeat\)](#)

To complete the products and construction of the balcony, use the sections below, while following the instructions in the comments.

[THE RESULT OF THE `` SLAB SIZE '' CALCULATION SHOWS THE DIMENSION OF THE CONCRETE BALCONY BY DEFAULT.](#)

[_2nd Balcony](#)

[_Balcony Standard](#)

[_Balcony Solage](#)

[_Slab Support](#)

[_Balcony Column](#)

[_Balcony Ramp](#)

[_Cold Room](#)

11- Construction of basement terrace. (Possibility of 2)

Follow the instructions coming from the cursor.

Enter the length and width of the deck and the software will calculate and compile all the products of the flooring and deck reinforcement etc.

Number of Terrace

Quantity of Terrace

House wall Length

Side of the slab

[Surface Modification \(to repeat\)](#)

SAVE

To complete the products and construction of the terrace, use the sections below, while following the instructions in the comments

[Terrace Standard](#)

[Wall Protection Antifreeze](#)

[Terrace](#)

[2nd Terrace](#)

[Wall on Foundation](#)

[Ceiling](#)

[Extra Product](#)

12-Project administration.

Follow the instructions coming from the cursor.

THIS STEP CONTAINS THE OPTIONS TO COMPLETE THE SPECIFICITIES OF THE PROJECT ON THE SELECTED LAND.

THIS STEP CONTAINS THE OPTIONS TO COMPLETE THE SPECIFICITIES OF THE PROJECT ON THE SELECTED LAND.

_Land Details

_Excavation

_Municipal Service

_Professional and other Services

._Landscaping

_Structure

Floor

Walls

Installation of products on external walls.

Ceiling

Roof

_Submission

