

THIS PAGE IS USED FOR ADVISORY PURPOSES ONLY

THE USER MUST USE AN EXISTING PAPER OR ELECTRONIC PLAN AND MUST BE FAMILIAR WITH READING A PLAN

BY ENTERING THE FEW MEASUREMENTS REQUESTED AND CONFIRMING THE SELECTION OF OPTIONS, THE SOFTWARE CALCULATES THE PLAN STATEMENT ITSELF AND TRANSFERS BY DEFAULT THE QUANTITIES OF THE PRODUCTS AND THEIR LOCATIONS TO EACH PURCHASE ORDER OF THE PROJECT.

. THE PREDICTION OF THE COMPUTATION TIME OF EACH STEP IS QUANTIFIED IN PARENTHESES

Sommaire

1-Registerer a new project (Negligible ) .....	2
2-(Steps) Select the steps of the project. (Negligible ) .....	5
3 (Foundation) Record foundation measurements (Negligible) + adjustments (+/- 5 minutes).....	6
4-(Basement) Display of basement's basic products (Instant display) + adjustments (+/5 minutes) .....	9
5- (Floors) Display of the upper floors' basic products. (Instant display)+ Adjustments (+/- 10 minutes) per floor.	11
6-(Garage) Record the measurements of the garage. (Negligible) + Adjustments (+/- 5 minutes) .....	14
7.1- Rooms (e.g. bedroom) Add a new room (Negligible) each .....	18
7.2- Rooms (e.g. bedroom) Dress up this piece using the files below. (+/- 5 minutes) each .....	23
8.1-(Roof) Record the measurements of each identical roofing panel. (Negligible) each .....	27
8.2-(Roof) Adjust these panels if necessary using the sections below (+/- 5 minutes).....	29
9-(Balcony) Write down the measurements of the balcony (Negligible) + Adjustments (+/- 5 minutes).....	33
10-(Terrace) Record the measurements of the terrace basement. (Negligible)+Adjustments (+/-5 minutes) .....	35
11-(Adjustments) Set up a field and manage the administration of the project (+/- 10 minutes). .....	40

## 1-Registrer a new project (Negligible )

THIS PAGE ALLOWS YOU TO VIEW THE INSTALLATION OF A NEW PROJECT  
When opening the homepage, the software displays a table on the screen. Click ADD

A table appears or you need to name the project and click SAVE A green board appears on the screen confirming that you have saved the project. This green board should always appear after completing each box in the software.

Name

Type

Datasheet

SAVE

The new project you have saved, will be displayed in the list of projects. Click the project drop-down arrow and target the project in the list of projects. Click on the project you want to use and then click on the ACCESS cell to display it on the screen.

t

t

To access an existing project from the list, click on the drop-down arrow of projects and choose the project you want. Click on this project and then click ACCESS to display it on the screen.





## 2-(Steps) Select the steps of the project. (Negligible )

The software shows the steps you've selected at the top of the screen and hides the ones you don't use.

CHECK THE STEPS YOU'VE CHOSEN TO CREATE A PROJECT.

Once the project has been named, the software then displays on the screen the steps you can select to build the project.

THE ADJUSTMENT STEP SHOULD ALWAYS BE CHECKED.  
ALWAYS SAVE.

- Adjustments
- Foundation
- Basement
- Basement Wall
- Concrete Balcony
- Garage
- Basement Patio
- 1st Floor
- 2nd Floor
- 3rd Floor
- 4th Floor
- 5th Floor
- 6th Floor
- Roof
- Inner Room

SAVE

**You now have all the tools to build your project**

### 3 (Foundation) Record foundation measurements (Negligible) + adjustments (+/- 5 minutes).

ENTERING THE TWO FOUNDATION MEASUREMENTS INSTANTLY RECORDS THE COMMODITIES IN THE PURCHASE ORDERS FOR THE FOLLOWING STAGES: FOUNDATIONS, BASEMENT, BASEMENT WALLS, AND THE SELECTED FLOORS (6 POSSIBLE) OF THE PROJECT.

Enter the width and length of the foundation (precision required) and the software will enter the quantity of base products, floors, ceilings and exterior walls of the foundations, basement and floors (6) selected from the project.

Enter the length and width (plus adjustments) of the foundations to find the area and perimeter of the foundations that the software will use to activate project queries.

#### Starting Measures

Floor Facade

40.000	Foot
--------	------

Floor Side

40.000	Foot
--------	------

No step requires additional calculation to calculate the commodities of each step.

The software calculated with these measurements, 8' and 8'' thick foundations, calculated the insulation of the solage and its waterproofing etc.

Use the files below to add windows to the flooring, change the thickness of the floor and the insulation of the walls, add interior jogging, and pilafs etc.

[Basic Foundations](#)

[Concrete](#)

[Solage](#)

[Opening of Foundations](#)

[Concrete Columns](#)

[Interior Footing](#)







#### **4-(Basement) Display of basement's basic products (Instant display) + adjustments (+/5 minutes)**

ALL THE BASIC PRODUCTS OF THE SUBSOIL COME DIRECTLY FROM THE RESULT OF THE FOUNDATION MEASUREMENTS..

**Use the files below as needed to add partitions, load walls, concrete blocks, etc.**

*THE RESULT OF THE CALCULATION OF "FOUNDATION MEASURES " IS TRANSFERRED BY DEFAULT TO ALL THE SELECTED STAGES OF THE PROJECT.*

*\_Basic Foundations*

*\_Concrete*

*\_Solage (Modifications)*

*\_Opening of Foundations*

*\_Concrete Columns*

*\_Interior Footing*

*\_Interior Solage*

*\_Exterior Solage*

*\_Curbstone*

*\_Antifreeze*



## 5- (Floors) Display of the upper floors' basic products. (Instant display)+ Adjustments (+/- 10 minutes) per floor.

**ALL THE BASIC PRODUCTS FOR THE UPPER FLOORS OF THE PROJECT COME DIRECTLY FROM THE RESULT OF THE FOUNDATION MEASUREMENTS.**

**If the floor measurements have changed, use the following boxes to change them.**

Choice of Dimensions

- (1st) Already Programmed Dimension
- (2nd) New Dimensions

ADD.

By default, each floor displays the products of the floors, ceilings, and walls of each floor.

Use the files below as needed to add partitions, load walls, concrete blocks, etc.

***THIS FLOOR RECEIVES BY DEFAULT THE SURFACE OF THE FLOOR AND CEILING AS WELL AS THE PERIMETER OF THE WALLS FROM THE "FOUNDATION" STEP.***

[Base Floor](#)

[Exterior Wall](#)

[Floor](#)

[Ceiling](#)

[Partition](#)

[Bearing Wall](#)

[Concrete's Block](#)

[Installation of concrete's blocks to stage's wall. \(Open for installation\)](#)

[Concrete Wall](#)

[Common Wall](#)

[Coating NO.1](#)

[Coating NO.2](#)

[Coating NO.3](#)





Haut du formulaire

## 6-(Garage) Record the measurements of the garage. (Negligible) + Adjustments (+/- 5 minutes)

ALL BASIC PRODUCTS FOR THE BASEMENT, FLOOR, CEILING AND EXTERIOR WALLS OF THE GARAGE COME BY DEFAULT FROM THE RESULT OF THE RECORDING OF THE TWO MEASUREMENTS OF THE GARAGE.

**Enter the length and width of the garage and the software will calculate and compile all the foundation, floor, and ceiling and garage wall products.**

### Dimension

Garage Length

 

Garage Width

 

*Square Surface (to repeat)*

*Standard Solage*

*Solage*

*Interior Solage*

*Exterior Solage*

*Floor*

*Ceiling*

*Exterior Wall*

*Wood Partition*

*Bearing Wall*

*Wall Concrete Blocks*

*Coating NO.1*

*Coating NO.2*

*Installation of a coating different from the main coating on a new length of exterior wall on this floor*









---

## 7.1- Rooms (e.g. bedroom) Add a new room (Negligible) each

Use the calculation method taught in Step 3.

### Room Dimension

Width

0.000	Foot
-------	------

Length

0.000	Foot
-------	------

[Adjust Surface \(to repeat\)](#)

[Triangular Surface \(to repeat\)](#)

SAVE

### Identify the project.

Confirmation

### Type of Building

TEXT	Unit
------	------

### Identification of Room

### Identification of this piece.

Room Name

TEXT	Unit
------	------

SAVE

### Locate the part

SÉLECTION D'ÉTAGE

- (1st) No Floor
- (2nd Choice) Basement
- (3rd Choice) 1st Floor
- (4th Choice) 2nd Floor
- (5th Choice) 3rd Floor
- (6th Choice) 4th Floor

(7th Choice) 5th Floor







**7.2- Rooms (e.g. bedroom) Dress up this piece using the files below. (+/- 5 minutes) each**

**To complete the products and dress up the pieces, use the sections below while following the instructions in the comments.**

*THE RESULT OF THE CALCULATION OF " MEASURES " SHOWS BY DEFAULT THE PRODUCTS AND LABOR OF THE ORDER FOR THE PART.*

*Products*

*Gypsum*

*Floor Covering*

*Paint*

*Mouldings*

*Access Hatch*

*Mechanical*

*Wardrobe*

*2nd Wardrobe*

*Wall Openings*

*Plastering*









**8.1-(Roof) Record the measurements of each identical roofing panel.  
(Negligible) each**

**Identify the number and type of identical panels used.**

---

Identical Panels

Quantity

Unit

- (1s) None
- (2nd) Four Square Angles
- (3rd) Two Square Angles
- (4th) One Square Angle or Less

SAVE

**Enter the dimensions of the panels.**

Panel Measurements

Top of Panels

Foot

Bottom of Panels

Foot

Height

Foot

Slope

Unit

SAVE



**8.2-(Roof) Adjust these panels if necessary using the sections below (+/- 5 minutes)**

**Choosing the thickness of the cornices**

**Cornice Columbine**

2 " X 4 " x 12 '

Unit

2 " X 6 " x 12 '

Unit

2 " X 8 " x 12 '

Unit

2 " X 10 " x 12 '

Unit

2 " X 12 " x 12 '

Unit

**SOFFITE**

LOCALISATION SOFFITE  
BAS DES PANNEAUX

Inch

CORNICHES DE PIGNON

Inch

**Use the files below to add different products to the roof, etc.**

*\_THE RESULT OF THE CALCULATION OF THE SUB-SECTIONS BELOW SHOWS BY DEFAULT THE PRODUCTS AND LABOR OF PURCHASE ORDERS FOR SIMILAR ROOF PANELS.*

*\_Roof Products*

*\_Roof Pinion*

*\_Carport*

*\_Common Roof*

*\_Chimney*

*\_Ventilation*

*\_Flat Roof With Truss*

*\_Balcony*

*Ceiling Cathedral*







---

**9-(Balcony) Write down the measurements of the balcony (Negligible) + Adjustments (+/- 5 minutes)**

**Enter the length and width of the balcony and the software will calculate and compile all the products of the slab, slab reinforcement etc.**

Square Surface (to repeat)

ACCESSADDREMOVE

Length

 

Width

 

[Square Surface Adjustment \(to repeat\)](#)

**To complete the products and construction of the balcony, use the sections below, while following the instructions in the comments.**

[THE RESULT OF THE `` SLAB SIZE '' CALCULATION SHOWS THE DIMENSION OF THE CONCRETE BALCONY BY DEFAULT.](#)

[\\_2nd Balcony](#)

[\\_Balcony Standard](#)

[\\_Balcony Solage](#)

[\\_Slab Support](#)

[\\_Balcony Column](#)

[\\_Balcony Ramp](#)

[\\_Cold Room](#)



**10-(Terrace) Record the measurements of the terrace basement.  
(Negligible)+Adjustments (+/-5 minutes)**

**Enter the length and width of the deck and the software will calculate and compile all the products of the flooring, flooring and deck reinforcement etc.**

Number of Terrace

Quantity of Terrace

Unit

House wall Length

0.000 Foot

Side of the slab

0.000 Foot

[Surface Modification \(to repeat\)](#)

SAVE

**THE RESULT OF THE CALCULATION OF "BASEMENT TERRACE" DISPLAYS THE DIMENSION OF THE BASEMENT TERRACE BY DEFAULT. To complete the products and decking work, use the sections below while following the instructions in the comments.**

THE RESULT OF THE "BASEMENT TERRACE" CALCULATION SHOWS THE DIMENSION OF THE BASEMENT TERRACE BY DEFAULT.

*To complete the products and construction of the terrace use the sections below while following the instructions in the comments.*

*\_2nd Terrace*

*\_Terrace Standard*

*\_Wall Protection Antifreeze*

*\_Wall on Foundation*

*\_Ceiling*

*\_Extra Products*







**11-(Adjustments) Set up a field and manage the administration of the project (+/- 10 minutes).**

*THIS STEP CONTAINS THE OPTIONS TO COMPLETE THE SPECIFICITIES OF THE PROJECT ON THE SELECTED LAND.*

*Land Details*

*Excavation*

*Municipal Service*

*Professional and other Services*

*Landscaping*

*Structure*



---

**Floor**

**Walls**

**Roof**

---

Ceiling

Roof

